


AUTO REFILL DIAGRAM



* device prompts for manual refill on recipe start if checkbox "B" in warnings menu is checked, else it starts with empty bubbler.